



Typical 10-digit Keypad Layout with Digital Eye Chart

Hot-key pattern for wireless keypad use.

Number-lock must be ON.




Control from Slide Show



Switch to charts from Slide show. "Dark Chart" darkens screen on all test charts. Return to slide show from any chart by pressing "6"

Control from Charts with Opto-types (i.e. standard, red/green, etc.)



To choose another chart press "6" to return to slide show. Up/Down arrow and Up/Down Page have different meanings depending on the specific chart. Refer to the hotkey cheat sheet or users manual for details.